Q8 BT headset User Guide

IMPORTANT SAFETY NOTICE: Prolonged exposure to high volume levels can damage your hearing. To avoid injury, set the volume to the lowest comfortable level. If you experience ringing in your ears, or voices sound muffled, stop using the headset. Avoid turning up the volume to block noisy surroundings. It's possible for your ears to adapt to volume that is too high, and this could result in permanent hearing damage without any noticeable discomfort.

- Check with local and state laws regarding cell phone / headset usage while operating a motor vehicle.
- Do not immerse any part of this product in water.
- Plastic bags and small parts may cause choking if ingested. Keep them away from small children and pets.
- Use only the power cords included with this product.
- Avoid temperatures exceeding 140°F (will cause equipment failure)

1. **Headset Overview**

|	
⏩ / ≪ ≫	Volume switch / Songs selection
☼	Indicator lights
🔋	Battery charge port
PTT/⏻	PTT/ Power on/off
☎ ▷ ❙❙	Call /Play/Pause

2. **How to wear the headset**

① Rotate the microphone rod to the vertical direction.
② Insert the headset to your ear and make sure it fit your ear well.
③ Rotate the microphone rod to the suitable direction.

3. **Getting Started**

3.1 Pairing to an Anytone radio or a cell phone

① Press and hold [**PTT**/ ⏻] button to turn on, red and blue lights will blink in turn, indicating the headset is in pairing mode.

② Put your Anytone radio or cellphone into blueooth search / scan mode.
  Anytone radio: "Menu" >> "Bluetooth" >> "BT On/Off" >> "Bluetooth On", turn the bluetooth on "Menu" >> "Bluetooth" >>" BT Pairing Seek BT", put the radio in bluetooth search mode.
  - **iPhone:** "Settings" > > "General" >> "Bluetooth" > > "On"
  - **Android**^{TM} Cell phone: "Settings" > > "Wireless & Networks" >> Bluetooth: ON >> Scan of devices

  NOTE: The menus might be different for different brand cellphones.

③ Select "**Q8**" named device to pair, the blue light will begin blinking when the headset is connected to the radio or cellphone.

3.2 To Multi connect to an Anytone radio and a cellphone

The headset allows you connect to an Anytone radio and a cellphone at the same time.

　① Pair the headset to Anytone radio.

　② Disconnect the AnyTone Bluetooth connection.

　③ Pair the headset to the cellphone.

　④ Turn on bluetooth in radio and cellphone, the headset will connect to both the radio and cellphone.

Make sure the headset is connected to the Anytone radio first, otherwise the PTT function on the headset (for Anytone radio) will be invalid.

3.3 To Make a call or accept a call

For Anytone radio use

When the headset is connected to an Anytone radio, it allows you press the [**PTT**/ ⏻] button to start either a transmit or a receive, press the [**PTT**/ ⏻] button again to end the transmit or receive.

Reminder: The PTT function is only valid for Anytone radios, it doesn't support any other two way radios so far.

For Cellphone use

① To Manually accept / reject an incoming call.

　When the call is coming in, the cellphone will prompt with the incoming call number, press the 🚫 button to accept the call, or press and hold the 🚫 button to reject the call.

② To Voice answer / reject an incoming call

　When the call is coming in, you can say "**YES**" to accept or "**NO**" to reject.

NOTE: This function may not be reliable in particularly noisy environments.

③ To Call back the previous call

　Quickly tap the call button 🚫 twice to call back the previous call.

3.4 Music playing Pause / Volume Switch / Songs selection

　① To Pause the Play: When music is playing, click on the 🚫 button to pause, click on the 🚫 button again to play.

　② To adjust the Volume: When music is playing, push and hold the 🔊 /≪≫ button to change the volume.

　③ To Change Song selection: When music is playing, push the 🔊 /≪≫ button once to select the next or previous song.

3.5 To Switch languages

Turn on the headset, double click [**PTT**/ ⏻] and + 🔊 / ≪ ≫ keys together, the headset will prompt in different language, release the key when the language stops on the one you want to use.

4. Charging the headset

When the power is low, the headset emits a "**didi**" beep at 5 minutes intervals, after 4 "**didi**" beeps, it will remind you to "**Power off**", please charge the headset in time.

The red LED light is on when charging the headset. When the battery is fully charged, the LED will turn to blue light.

NOTE: To avoid a dead battery, make sure you charge the headset at least once per month even if you are not using it.

5. Specifications:

- Bluetooth 5.0
- Hi−Fi SBC, MP3, ACC, Digital audio decode
- S3D enhanced stereo (high quality, Hi−Fi, enhanced digital stereo)
- Voice recognition for call answer or rejection
- Voice dial (need the mobilephone support)
- CVC wideband voice and narrowband voice connection with wind suppression
- Allows connect the sub headset
- Supported profiles: AVRCP, HFP V1.6(Wideband Speech), HSP 1.2, mobilephone
- Power supply: 5V DC − 180mA
- Operation Temperature: 32°F − 104°F (0 − 40°C)
- Store Temperature: 32°F − 104°F (0 − 40°C)
- Charge Temperature: 32°F − 104°F (0 − 40°C)